

Loadindex Li							
Li	Kg	Li	Kg	Li	Kg	Li	Kg
65	290	85	515	105	925	125	1650
66	300	86	530	106	950	126	1700
67	307	87	545	107	975	127	1750
68	315	88	560	108	1000	128	1800
69	325	89	580	109	1030	129	1850
70	335	90	600	110	1060	130	1900
71	345	91	615	111	1090	131	1950
72	355	92	630	112	1120	132	2000
73	365	93	650	113	1150	133	2060
74	375	94	670	114	1180	134	2120
75	387	95	690	115	1215	135	2180
76	400	96	710	116	1250	136	2240
77	412	97	730	117	1285	137	2300
78	425	98	750	118	1320	138	2360
79	437	99	775	119	1360	139	2430
80	450	100	800	120	1400	140	2500
81	462	101	825	121	1450	141	2575
82	475	102	850	122	1500	142	2650
83	487	103	875	123	1550	143	2725
84	500	104	900	124	1600	144	2800

Opmerking:
 Staan er twee getallen voor de loadindex op de band dan staat het eerste getal voor enkellucht montage en het tweede voor dubbellucht montage.

Speedindex	
	km/u
L	120
M	130
N	140
P	150
Q	160
R	170
S	180
T	190
H	210
V	240
W(ZR)	270
Y(ZR)	300
ZR	>240



Bandenspanning		
bar	PSI	kpa
0,0	0	0
0,5	7	50
1,0	15	100
1,5	22	150
2,0	29	200
2,5	36	250
3,0	44	300
3,5	51	350
4,0	59	400
4,5	65	450
5,0	73	500
5,5	80	550
6,0	87	600
6,5	94	650
7,0	101	700
7,5	109	750
8,0	116	800